



## Schlupf Precision Ag

Kinze 3000 Series vSetSelect box instructions (price \$135 / row)

574-518-4693

- 1) Lower planter so row units are resting on floor
- 2) Remove hopper box, seed drive chain
- 3) Remove insecticide box and support panel if installed
- 4) Remove OEM hopper support panel, row unit stops, making sure to have row unit shank supported when rear upper parallel arm bolts are removed
- 5) Install new right and left hopper support side panels, row unit stops, leaving bolts loose.
- 6) When installing upper parallel arm bolts (new 5/8"x2 3/4"), also install .5" x 2.25" spacer between goalpost and front hopper box mount
- 7) install rear hopper support cross piece to side panels using supplied 3/8" x 3/4" carriage bolts and serrated nuts (on inside of panels), leaving loose. Install lower 3/8" bolt removed earlier to mount cross piece to cast Kinze depth gauge bracket. The hole in the casting may vary, requiring a lineup punch to slightly "egg shape" our bracket to get bolt in.
- 8) Before tightening all bolts, make sure side panels are level. Tighten all bolts double checking that everything stays lined up and true
- 9) Remove hopper latch from Kinze hopper support and mount in same way on new hopper support
- 10) Set hopper box on frame and check meter seed exit tube to seed tube alignment. Making sure it is centered side to side. If necessary a 5/8" flat washer (supplied) can be installed between goalpost and 1/2" spacer to move box slightly to the right or left

Option:

Adapter for Kinze 2000 series and JD 7000 planters \$18.50

